



Performance Cold Air Intake Kit Part Number: 837-110

**Honda 1992-1995 Civic
SOHC D Series
DOHC B Series**

Installation Instructions

For technical inquiries please email us at tech@hpsperformanceproducts.com

In the email, please include the following information for faster response:

- Year / Make / Model / Engine of your vehicle.
- If it is a fitment issue, please include pictures showing the fitment problem.
- If there are missing parts, please list the part number(s) from the bill of materials on the 2nd page.
- Optional but recommended – Your contact phone number and preferred call back time.

You can also give us a call via 626-747-9200 for tech support Monday-Friday, 9:00am-5:00pm Pacific Time.

Bill of Materials

Part Number: 837-110

Description	Prep	Part Number	Qty	Check
Short Ram Intake Pipe	1	529-101	1	
Cold Air Intake Pipe	1	529-102	1	
HPS Filter	2	HPS-4275	1	
T-Bolt Clamp 2.5" Hose	3	SSTC-67-75	1	
T-Bolt Clamp for 2.75" Hose	3	SSTC-73-81	4	
2.75" silicone coupler x 2.5" Long	3	P3SC-275-L25	1	
2.5" to 2.75" Silicone Coupler x 2.5" Long	3	P3SR-250-275-L25	1	
2.75" Hump Coupler x 3" Long	3	P3SHC-275-L3	1	
9.5mm breather hose EPDM x 14" Long	3	EPDM-038	1	
Upper pipe Bracket	3	529-100	1	
Lower pipe bracket	3	529-103	1	
6mm Rubber Mount x 1/2" Tall	3	HW-RM6-50	2	
6mm Large OD Washer	3	HW-FW6L	4	
6mm X 12mm long Hex Bolt	3	HW-B6-12	2	
6mm Flange Nut	3	HW-N6	2	

- Before installing any parts of this intake system, please read the instructions thoroughly.
- Verify the contents of this intake kit before disassembling your vehicle.
- DO NOT INSTALL IF ANY PARTS ARE MISSING OR DAMAGED. CONTACT tech@hpsperformanceproducts.com IMMEDIATELY. WE ARE NOT RESPONSIBLE FOR ANY DAMAGE CAUSED DUE TO IMPROPER INSTALLATION.
- Installation requires moderate mechanical skills. A qualified mechanic is highly recommended.
- Do not attempt to install the intake system while the engine is hot.
- This installation may require removal of coolant lines that may be hot.
- For technical inquiries, please e-mail us at tech@hpsperformanceproducts.com

PLEASE READ CAREFULLY BEFORE INSTALLATION!

This installation is not for the novice customer. Install this product with EXTREME caution! Misuse of this product can destroy your engine! If you are not mechanically inclined, please have a professional automotive mechanic install this kit.

NOTE: HPS holds no responsibility for any engine damage that results from misuse of this product.

GETTING STARTED

1. Turn the ignition OFF and disconnect the vehicle's negative battery cable. If the engine has run within the past two hours, let it cool down.

NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicle's anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicle's anti-theft code. We also highly recommend NOT discarding any stock parts after the installation.



2. Remove the clamp on the factory air intake hose from the throttle body. Remove the breather hose from the valve cover.



3. Remove the bolts securing the airbox to the chassis, then remove the airbox and air intake hose from the engine bay.



4. Install the 2.5" long silicone coupler and T-bolt clamps onto the throttle body. (For D-series engine, install silicone reducer instead.)




5. Install the HPS intake pipe onto the throttle body. Do not tighten the clamps yet. Install the breather hose included in the kit.



6. Install the rubber mount and intake bracket using the hardware included.



7. To complete the installation as a short ram intake, install the air filter onto the end of the upper pipe. To install the cold air intake, continue to step 8.



8. Remove the front bumper and insert the lower intake pipe in through the opening behind the headlight. Install the bracket and rubber mount using the hardware supplied.



9. Install the hump coupler between the upper and lower intake pipe using and secure using the T-bolt clamps included in the kit.



10. Install the air filter to the end of the lower intake pipe.



Final Steps

Once the intake has been positioned, tighten all of the clamps and secure all of the parts.

Upon completion of the installation, reconnect the negative battery terminal before you start the engine. Double check to make sure everything is tight and properly positioned before starting the vehicle.

Start the engine. Let the car idle for 3 minutes. Perform a final inspection before driving. Listen carefully for any odd noises, rattles and/or air leaks prior to taking it for a test drive. If any problems arise go back and check the vacuum lines, hoses and clamps that may be causing leaks or rattles and correct the problem.

Periodically, recheck the alignment of the intake system and make sure there is proper clearance around and along the length of the intake. Failure to follow proper maintenance procedures may cause damage to the intake and will void the warranty.

This HPS performance cold air intake system has been designed to be used in two different configurations. In the case of inclement weather, the cold air tube can be removed and the air filter can be clamped onto the intake tube located in the engine compartment to avoid the possibility of ingesting water into the engine.