



Performance Cold Air Intake Kit Part Number: 837-555

Honda 2013-2017 Accord 2.4L 4cyl

Installation Instructions

For technical inquiries please email us at tech@hpsperformanceproducts.com

In the email, please include the following information for faster response:

- Year / Make / Model / Engine of your vehicle.
- If it is a fitment issue, please include pictures showing the fitment problem.
- If there are missing parts, please list the part number(s) from the bill of materials on the 2nd page.
- Optional but recommended – Your contact phone number and preferred call back time.

You can also give us a call via 626-747-9200 for tech support Monday-Friday, 9:00am-5:00pm Pacific Time.

Bill of Materials

Part Number: 837-555

Description	Prep	Part Number	Qty	Check
Upper Air Intake Pipe		529-244	1	
Cold Air Intake Pipe		529-245	1	
HPS Air Filter		HPS-4275	1	
T-Bolt Clamp for 2.62" Hose		SSTC-70-78	1	
T-Bolt Clamp for 2.75" Hose		SSTC-73-81	3	
2.62" - 2.75" Reducer x 2" Long		P3SR-262-275-L2	1	
2.75" Hump Hose		P3SHC-275	1	
M4 bolts		HW-B4-8	2	
6mm Bolt 12mm long		HW-B6-12	3	
6mm Flange Nut		HW-N6	1	
6mm Flat Washer 16mm OD		HW-FW6L	4	
Rubber Vibration Mount 6mm 1/2" Tall		HW-RM6-50	1	
12.7mm EPDM hose, 2" length		EPDM-050	1	
Short Ram Bracket		530-246	1	
Cold Air Bracket		530-247	1	

- Before installing any parts of this intake system, please read the instructions thoroughly.
- Verify the contents of this intake kit before disassembling your vehicle.
- DO NOT INSTALL IF ANY PARTS ARE MISSING OR DAMAGED. CONTACT tech@hpsperformanceproducts.com IMMEDIATELY. WE ARE NOT RESPONSIBLE FOR ANY DAMAGE CAUSED DUE TO IMPROPER INSTALLATION.
- Installation requires moderate mechanical skills. A qualified mechanic is highly recommended.
- Do not attempt to install the intake system while the engine is hot.
- This installation may require removal of coolant lines that may be hot.
- For technical inquiries, please e-mail us at tech@hpsperformanceproducts.com

PLEASE READ CAREFULLY BEFORE INSTALLATION!

This installation is not for the novice customer. Install this product with EXTREME caution! Misuse of this product can destroy your engine! If you are not mechanically inclined, please have a professional automotive mechanic install this kit.

NOTE: HPS holds no responsibility for any engine damage that results from misuse of this product.


GETTING STARTED

1. Turn the ignition OFF and disconnect the vehicle's negative battery cable. If the engine has run within the past two hours, let it cool down.


NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is re-connected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicle's anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicle's anti-theft code. We also highly recommend NOT discarding any stock parts after the installation.



2. Disconnect breather pipe from intake tube.



3. Disconnect and unclip the MAF sensor harness from the air box.



4. Unscrew the hose clamp on the air box.



5. Unscrew the hose clamp on the throttle body.



6. Carefully remove the stock intake hose from the engine bay.



7. Remove the 2 bolts holding down the air box to the chassis using a 10mm socket and remove the air box from the engine bay.




8. Install the silicone reducer onto the throttle body and secure it using the smaller t-bolt clamp. Loosely fit the larger t-bolt clamp onto the coupler as shown.



9. Insert the HPS intake pipe into the coupler on the throttle body. Install the stock MAF sensor onto the HPS intake pipe using the 4mm screws supplied in the hardware pack.



10. Attach the ½" EPDM hose included in the hardware pack onto the breather port.



11. Install the rubber mount onto the factory air box mounting location as indicated in the photo.



12. Install the intake bracket onto the rubber mount, then secure the bracket to the intake pipe using the hardware provided.



13. Install the heat shield and HPS air filter onto the intake pipe.

*** Skip this step if installing cold air intake**

14. Refer to your vehicle's service manual to remove the front bumper



15. Locate and remove the plastic rivet on the fender liner attached to the resonator.



16. Unbolt the 2 bolts on the resonator and remove it from the vehicle.



17. Install the hump coupler with the t-bolt clamps onto the upper intake pipe.



18. Insert the cold air pipe and attach it to the hump coupler.



19. Install the bracket for the cold air pipe as shown using a M6 bolt and washer at each location.



20. Install the air filter onto the cold air pipe.




Final Steps

Once the intake has been positioned, tighten all of the clamps and secure all of the parts.

Upon completion of the installation, reconnect the negative battery terminal before you start the engine. Double check to make sure everything is tight and properly positioned before starting the vehicle.

Start the engine. Let the car idle for 3 minutes. Perform a final inspection before driving. Listen carefully for any odd noises, rattles and/or air leaks prior to taking it for a test drive. If any problems arise go back and check the vacuum lines, hoses and clamps that may be causing leaks or rattles and correct the problem.

Periodically, recheck the alignment of the intake system and make sure there is proper clearance around and along the length of the intake. Failure to follow proper maintenance procedures may cause damage to the intake and will void the warranty.



HPS Silicone Radiator + Heater Hose Kit (Black/Blue/Red) with Stainless Steel Clamps is now available for Honda 13-15 Accord 2.4L !

Part Number: 57-1387



**Contact our authorized dealers for the best pricing
or
Visit our website at www.hpsperformanceproducts.com for more details**